



Selection Guide: RF Connector Adapters

RF CONNECTOR ADAPTERS

Series 852 RF Adapters

Precision-grade *Series 852 RF Adapters* are used to connect between series or within a series. Frequently used as connector savers, male-female adapters protect RF jacks on instruments from excessive wear-and-tear. 45° and 90° angled SMA male-female adapters provide extra clearance in cramped quarters.



TNC-SMA Adapters Page 18



TNC Male-SMA Female
852-160



TNC Female-SMA Female
852-161



TNC Female-SMA Female,
Square Flange
852-162



TNC Female-SMA Female,
Jam Nut
852-163

N-SMA Adapters Page 19



N Male-SMA Female
852-164



N Female-SMA Female
852-165



N Female-SMA Female,
Jam Nut
852-166



N Female-SMA Female,
Square Flange
852-167

SMA-SMA Adapters Page 20, 21



SMA Male-SMA Female
852-168



SMA Female-SMA Female
852-169



SMA Female-SMA Female,
Jam Nut
852-170



SMA Male-SMA Female,
45° Angle
852-183



SMA Male-SMA Female,
90° Angle
852-182

SMP-SMA Adapters Page 22



SMP Male-SMA Female
Full Detent
852-173



SMP Male-SMA Female
Smooth Bore
852-174



SMP Female-SMA Female
852-175

2.92-SMA Adapters Page 23



2.92 Male-SMA Female
852-171



2.92 Female-SMA Female
852-172

BNC-SMA Adapters Page 24



BNC Male-SMA Female
852-189