


IRT Series
Rectangular Multi Pole Power Connector
Components Exploded View




IRT Series Components Exploded View

Receptacle Connector




Receptacle Connector

- 1 - Receptacle Shell
- 2 - Front Insert
- 3 - Contact
- 4 - Rear Insert
- 5 - Backend Adapter
- 6 - Clamp



IRT Series Components Exploded View

Plug Connector



Plug Connector

- 7 - Plug Shell
- 8 - Front Insert
- 9 - Contact
- 10 - Rear Insert
- 11 - Backend Adapter
- 12 - Clamp